



ASSEMBLY GUIDELINES

THIS CUSTOM RECESSED SCREEN IS DESIGNED TO HAVE A UNIVERSAL FIT AND FEATURES A WIDE RANGE OF ADJUSTMENT. FOR THE BEST RESULTS LAYOUT ALL OF THE PARTS ON THE FLOOR IN FRONT OF YOUR FIREPLACE. TAKE PARTICULAR NOTICE OF ALL OF THE SLIDE MOUNTING FEATURES ON THE ASSEMBLY. THESE ALLOW FOR THE ADJUSTMENTS NECESSARY TO ARCHIVE A CUSTOM FIT. EXAMINE YOUR FIREPLACE AND LOCATE YOUR LINTEL IRON (BAR ACROSS FIREPLACE OPENING). YOU MAY NOW BEGIN THE ACTUAL INSTALLATION.

1.) CHECK ROD AND FACEPLATE ASSEMBLY FOR FIT IN THE FIREPLACE OPENING.
2.) LOCATE THE LINTEL BAR IN YOUR FIREPLACE CHECK LINTEL CLAMPS (PROVIDED) FOR FIT.

3.) NOTE LOCATION OF ADJUSTING BOLTS ON ROD ASSEMBLY THESE WILL BE THE FINAL ADJUSTMENT FOR SCREEN HEIGHT.

4.) INSTALL LINTEL CLAMPS ON ROD ASSEMBLY WITH THE BOLTS PROVIDED.

5.) ATTACHE ASSEMBLY TO LINTEL AND TIGHTEN THUMB SCREWS PROVIDED.

6.) INSTALL CURTAIN MESH ON ROD. WITH TASSEL PULLS TOWARD THE CENTER OF ASSEMBLY

7.) ADJUST HEIGHT OF ROD USING BOLTS AT EACH END AND IN THE CENTER, SO THE CURTAIN MESH STAYS ABOVE THE FLOOR OF THE FIREPLACE, CHECK FIT WITH THE MESH OPEN AND CLOSED.

IF CORNER FIREPLACE INSTALL LARGE SIZE FIRST!

8.) THEN PREPARE THE SHORT SIZE ASSEMBLY IN THE SAME MANNER.

9.) THE SHORT FACEPLATE MAY NOT HAVE TWO MESH CURTAINS. IF IT HAS A SINGLE MESH THEN INSTALL WITH THE PULL TOWARD THE LARGER SCREEN.

10.) WHILE INSTALLING THE SMALL SECTION PLACE THE CORNER FACEPLATE CLIP ON BOTH FACE PLATES.

11.) USING THE ADJUSTING BOLTS ADJUST THE LEVEL OF THE BAR.

12.) FINALLY TIGHTEN ALL OF THE NUTS, BOLTS AND THUMBSCREWS ON THE ASSEMBLY.

ENJOY!