



## Reddi Bilt Lintel For Masonry Fireplaces

# Installation Instructions

### INSTALLATION

1. Center lintel in fireplace and level. **Make sure the 3/8" bar rests on top of the finished hearth.** (The exposed bar will be covered after the fireplace glass enclosure is installed.)

**▲ WARNING: Do not sink 3/8" bar! The fireplace glass enclosure design for this lintel will not fit!**  
2. Build your brick or stone evenly up both sides and across top. **Leave a 1/2" mortar bead around outer lip to create a smooth surface for the glass enclosure to lay up against.**

**NOTICE: It is important that the 3/8" bar is fully exposed and the outer lip has a 1/2" mortar bead around it, to insure a tight fit of the glass enclosure to the lintel.**

