

READ ALL INSTRUCTIONS BEFORE CONTINUING

1. Place shelf mantel on the wall at desired height. Position mantel centered over fireplace.
2. Using a pencil, mark across the top leaving a faint line. Remove the mantel and set it aside.
3. Measure down $\frac{3}{4}$ of an inch from the line you drew and draw another line.
4. Mount kleeing to the wall with 2 $\frac{1}{2}$ OR 3 inch screws (not provided) on the second line that you drew. Be sure to find the framing behind the drywall to secure the kleeet to. Secure in four or five places.
5. Place the mantel back into position. Pre-drill through the top and bottom of the mantel in four or five places. Use finish screws or nails to secure to kleeing.

