



App Setup and Usage

Note:

- The content of the app or the design is subject to change. Support for apps may be discontinued without notice, depending on the content provider’s policy.
- Adult use only.

Attention:

- When pairing a device with the fire pit, only one Bluetooth connection can be used. Turn Bluetooth “OFF” to allow other devices to connect to the fire pit.

Setting up the App:

1. Download the HPC Fire App from the Apple store or Google Play.
2. Ensure that there is power supplied to the fire pit.



Note:

- If power is already applied, disconnect and reconnect power.

3. Open the HPC Fire App, see Fig.1.
4. From the setup screen, enter 6 characters.
5. Enter a password and confirm the password.
6. Select your language, and press “Continue”.
7. Enable the Bluetooth.
8. Select search for devices, see Fig.2.
9. Select the Remote Igniter.
10. Enter the default security code 2345 and press “Connect”, see Fig.3. Repeat until App is connected to the fire pit.

Fig.1




Fig.2






Fig.3





Using the App:



Status

Power ON/OFF: Answer 2 safety questions when powering on unit.

Flame – HIGH/LOW

Timer – amount of time left before shut-off.

Troubleshoot Guide – tap the “link to online help.”

- Setup –
1. Timer ON/OFF and set the timer.
 2. Customize the fire pit's name.
 3. Customize the security code.



Dashboard

Igniter Indicator

Temperature Indicator

Timer – amount of time left before shutoff.

Website link to HPCFire.com